

Product name

Viropro UVC PRO 10 - Available 04/2021

Description and models

Designer professional system for safe air disinfection by ultraviolet radiation (UVC). For spaces of up to 40m²/100m³.

Technology

Air disinfection using low consumption ultraviolet radiation (UVC). Designed with a forced ventilation program that produces constant air circulation. It hides the ultraviolet radiation, guaranteeing the absolute safety of the people living in the area to be disinfected.



Technical Data

Aircirculation	<ul style="list-style-type: none">• 7-blade axial fan; Max. speed 4100 rpm; Max. sound 30 dB.• Recirculation flow UVC PRO 10:30 m3/h.
Colour	<ul style="list-style-type: none">• Silver
Disinfection	<ul style="list-style-type: none">• Disinfection by UVC radiation.• Wavelength: 254 nm.• Lamp format: fluorescent lamp, ozone free.• Unities: 1 lamp.• Duration: 9000 h.
Electronic	<ul style="list-style-type: none">• On/Off switch.
PowerSupply	<ul style="list-style-type: none">• AC 220 V.• Power: 36 W.
Structure	<ul style="list-style-type: none">• Aluminium.
Dimensions and weight	<ul style="list-style-type: none">• To Hang: 400 × 68 × 680 mm (LxWxH).• With Stand: 400 × 235 × 770 mm (LxWxH).• 8.2 kg.